

Effect Gizmo™

User's Manual



RJM Music Technology, Inc.

Effect Gizmo™

User's Manual

Version 2.0
November 5, 2012

RJM Music Technology, Inc.
2525 Pioneer Ave.
Suite 1
Vista, CA 92081
+1-760-597-9450
email: support@rjmmusic.com
web: www.rjmmusic.com

Copyright © 2012 RJM Music Technology, Inc. All Rights Reserved

Effect Gizmo, Amp Gizmo, MasterMind, Rack Gizmo, RG-16 and the RJM logo are trademarks of RJM Music Technology, Inc.

Table of Contents

Table of Contents	v
Introduction	1
Effect Gizmo Features	1
Controls and Connectors.....	4
Front Panel.....	4
Rear Panel.....	4
Special Features	7
Audio Buffer	7
Click Stopper	7
Front Panel MIDI Connector	7
Function Switching a.k.a. Controlling Your Amp.....	7
Stereo Loops	8
MIDI Usage	15
MIDI Continuous Controllers.....	15
Bank Selection	15
Backing Up Your Settings: SysEx Dump	16
Setup Mode	17
Selecting MIDI Channel and MIDI Options.....	17
MIDI Channels.....	17
Continuous Controller Ranges	17
GCX Compatibility Mode	18
CC Disable	18
Bank Select Enable	18
Saving MIDI Channel and Options	18
Invert Mode	18
Momentary Mode	18
Group Mode	19
Factory Reset.....	19
Troubleshooting	21
Grounding Issues	22
Specifications	23
Front Panel MIDI Connector	23
Effect Gizmo MIDI Implementation Chart	24
Warranty	27

Introduction


Thank you for purchasing the Effect Gizmo audio loop switcher. The Effect Gizmo has been designed to give you total control of your effects devices, effects pedals or other electronic equipment from a single MIDI footswitch.

The Effect Gizmo provides twelve audio loops and a professional quality audio buffer, all in a compact, single rack space design. Because the audio loops contain no active circuitry, the Effect Gizmo can work with any effects device regardless of signal level. Either four, or all twelve loops (depending on the model you purchased) can switch either mono, stereo or balanced signals using ¼" TRS jacks. The last four loops can also double as function switches, allowing you to use them to control channel switching and other features on amplifiers.


Effect Gizmo Features

- Twelve audio loops (eight grouped in series with an insert point after the first four loops, and four independent loops)
- Stereo or balanced capability on the last four loops (or on all loops, depending on the model purchased)
- Loops 9-12 can be used as function switches to control channel switching on most amplifiers that use ¼" footswitch jacks
- A high-quality audio buffer that can be bypassed or moved elsewhere in the audio path
- "Click Stopper" technology that reduces the click noise associated with relay-based switchers
- Works with all MIDI footswitches
- Responds to Program Change and Continuous Controller messages
- Easy programmability via front panel buttons and LEDs
- Up to 256 programs can be saved in memory
- High-quality relays for optimal sonic performance, compatibility and reliability
- Supports both latching and momentary switching modes
- Provides phantom power to compatible MIDI devices when used with 7-pin MIDI cable or 6 pin XLR cable

Front Panel



Rear Panel



Controls and Connectors

Front Panel

- 1. Input Jack** – This jack is connected to the rear panel From Front jack (7), and will pass a mono or stereo signal through to that connector.
- 2. Audio Loop Buttons** - These buttons turn audio loops 1 through 12 on and off. The LED above each button is lit when the corresponding audio loop is on.
- 3. Power LED** – Lights when the Effect Gizmo is powered on.
- 4. Write Button** – Hold this button for three seconds to save the current settings to memory. The LEDs will flash to confirm.
- 5. Front Panel MIDI Jack** – This connector provides two-way MIDI communication using a 6-pin XLR jack. Please refer to the Special Features section for more details. ***Important note!*** Do not connect MIDI devices to both the front panel MIDI input and the rear panel MIDI input at the same time! At best, it won't work, and in the worst case you can damage your equipment.

Rear Panel

[A note about jack normalling](#)

Many of the jacks on the Effect Gizmo are normalled, meaning that they are internally connected to another jack inside the unit. A pair of normalled jacks is indicated on the rear panel by a line leading from one jack to another. The signal is normalled from the front panel input, through the buffer, through the first 8 loops, and then through the Click Stopper circuit. All you need to use the first 8 loops are the cables that lead to and from each effects device you wish to connect. The last four loops are not normalled at all – this was done so that they may be used as function switches if desired.

Plugging a cable into either one of a pair of normalled jacks breaks the internal connection, so you may use patch cables to change the routing of the signal path to suit your needs.

- 6. Buffer In** – Input to the audio buffer circuit. This jack is normalled to the From Front jack (7) – if nothing is plugged into this jack or the From Front jack (7), then the two jacks are connected together internally. See the Special Features section for more information on the buffer.
- 7. Buffer Out** – Output from the audio buffer circuit. This jack is normalled to the Input 1-4 jack (8) – if nothing is plugged into this jack or the Input 1-4 jack (8), then the two jacks are connected together internally.
- 8. From Front** – Signal from the front panel Input Jack (5) appears at this jack. This jack is normalled to the Buffer In jack (5) – if nothing is plugged into this jack or the Buffer In jack (5), then the two jacks are connected together internally.

[About Audio Loops 1 through 4](#)

Audio Loops 1 through 4 are connected in series. Each loop is connected internally to the next. When a loop is off, the Send and Return jacks for that loop are bypassed. The audio signal passes through unchanged. Turning the loop on routes the guitar signal through the Send jack and connects the Return jack to the next loop, which inserts the connected effects device in the audio path.

9. Input 1-4 – Input to audio loops 1 through 4. This jack is normalled to the Buffer Out jack (6) – if nothing is plugged into this jack or the Buffer Out jack (6), then the two jacks will be connected together internally.

10. Send 1 through 4 – Connect your effects inputs here. When the loop is on, the audio signal will be output at the send jack. When the loop is off, the send jack is grounded and no signal is output.

11. Return 1 through 4 – Connect your effects outputs here. When the loop is on, signal sent to these jacks will be passed through to the next loop.

12. Output 1-4 – Output from loops 1 through 4. This jack is normalled to the Input 5-8 jack (12) – if nothing is plugged into this jack or the Input 5-8 jack (12), then the two jacks will be connected together internally.

[About Audio Loops 5 through 8](#)

Audio Loops 5 through 8 are connected in series in the same way Loops 1 through 4 are.

13. Input 5-8 – Input to audio loops 5 through 8. This jack is normalled to the Output 1-4 jack (11) – if nothing is plugged into this jack or the Output 1-4 jack (11), then the two jacks will be connected together internally.

14. Send 5 through 8 – Connect your effects inputs here. When the loop is on, the audio signal will be output at the send jack. When the loop is off, the send jack is grounded and no signal is output.

15. Return 5 through 8 – Connect your effects outputs here. When the loop is on, signal sent to these jacks will be passed through to the next loop.

16. Tuner Out – This is an additional output that can be used to connect a tuner. It is connected to the buffer output, so this jack only functions if the buffer is in use.

17. Output 5-8 – Output from loops 5 through 8. This jack is normalled to the CS In jack (17) – if nothing is plugged into this jack or the CS In jack (17), then the two jacks will be connected together internally.

18. CS In – Input to the Click Stopper circuit. This jack is normalled to the Output 5-8 jack (16) – if nothing is plugged into this jack or the Output 5-8 jack (16), then the two jacks will be connected together internally. See the Special Features section for more information on the Click Stopper.

19. CS Out – Output from the Click Stopper circuit.

[About Audio Loops 9 through 12](#)

Audio loops 9 through 12 are fully isolated – not electrically connected to each other in any way. Each loop has its own discrete input and output. When a loop is off, the Send and Receive jacks for that loop are bypassed, and audio signal passes unchanged from loop input to loop output. When a loop is on, the loop input is connected to the Send jack, and the loop output is connected to the Return jack, which inserts the connected effects device into the audio path.

20. Input (9 through 12) – Signal input to the corresponding audio loop.

21. Send/NC (9 through 12) – Connect your effects inputs here. When the corresponding loop is on, audio signal will be output at this jack. When the corresponding loop is off, this jack is grounded and no signal is output. (NOTE: This jack can also be used as a Normally Closed function switch – see the Special Features section for details).

22. Output/NO (9 through 12) – Signal output from the corresponding audio loop. (NOTE: this jack can also be used as a Normally Open function switch – see the Special Features section for details).

23. Return (9 through 12) – Connect your effects outputs here. When the corresponding loop is on, audio signal feeding this output will be passed through to the loop output.

24. MIDI Thru/Out – Any MIDI commands sent to the MIDI In port (22) are output unchanged through this output. This port also acts as a MIDI output from the purpose of sending MIDI SysEx dumps – see the MIDI Usage section for more details.

25. MIDI In – Connect your MIDI footswitch controller here to send incoming MIDI commands to the Effect Gizmo. NOTE: If your MIDI footswitch supports phantom power, you can connect a 7-pin MIDI cable here and the Effect Gizmo will provide phantom power to the footswitch. Phantom power is supplied by the same AC adapter that powers the Effect Gizmo. If you use a 9VAC adapter to power the Effect Gizmo, the phantom power output will be 9VAC. If you use a 12VDC adapter, the phantom power output will be 12VDC.

26. Gnd Lift – This switch controls whether or not the Effect Gizmo chassis is grounded. If the button is out, the chassis is grounded. If it is in, the chassis is not grounded. Please note that this button is recessed to prevent it from being pressed accidentally – when the button is “out”, it’s almost flush with the chassis. If you find you have audio hum due to a grounding problem, activating or deactivating this switch may eliminate the hum. Please refer to the Grounding Issues section for more information.

27. Power – Connect a 9VAC or 12VDC, 1 Amp (or higher amperage) power supply here. . The Effect Gizmo will accept either center positive or center negative polarity.

Important: Note that the Effect Gizmo uses a 9 Volt AC or 12 Volt DC power supply. Do NOT connect any other power supply to the unit. Many power supplies are very similar in appearance. Connecting the wrong power supply to the Effect Gizmo can damage the unit and void your warranty.

Special Features

Audio Buffer

Using long cables or many effects may degrade the guitar signal, causing it to lose clarity and definition. The audio buffer is used to “strengthen” the guitar signal and preserve sound quality. The effect may vary from subtle to significant, depending on the length and quality of cables and type of effects used in your rig.

Typically, the buffer is placed in the audio path before the first audio loop, but certain pedals such as wah pedals or germanium fuzz pedals work better without a buffer in front of them. In these cases, it’s best to route your signal through these pedals, then through the buffer, and then through the rest of your pedals.

The buffer also provides a path to ground, which can either help with - or cause - noise due to grounding issues, depending on the specifics of your rig. See the Grounding Issues section for more details.

Click Stopper

The Effect Gizmo uses relays to perform its switching. Relays are the cleanest, most transparent switching method available. The disadvantage of relays is that they can produce a slight click in your audio signal when they switch. This is more noticeable when using a high gain amplifier or overdrive and distortion pedals. The Click Stopper circuit found in the Effect Gizmo is designed to greatly reduce this click noise by muting the audio output briefly when the relays switch.

To most effectively use the Click Stopper, it should be the last thing in line before your signal goes into the input of your amplifier or preamp. If you’re using 8 or less pedals in front of your amp, all you need to do is connect the CS Out jack to the input of your amp. All the other connections (except the connections leading to and from each pedal) are done for you internally.

If you’re using all 12 audio loops for pedals in front of your amp, you should connect from the output of loop 12 into the input of the Click Stopper (CS In), and the Click Stopper output (CS Out) will connect to the input of your amp.

Front Panel MIDI Connector

The Effect Gizmo features a front panel MIDI connection. The connector is a 6 pin female XLR connector. The XLR connector was chosen because it locks tightly and is more durable than the standard MIDI connector.

RJM Music offers 6-pin XLR to standard MIDI adapter cables. This will allow you to plug any standard MIDI device into the front panel MIDI connector. The 6 pin XLR MIDI connector will also be supported on future RJM Music products such as the Mastermind GT MIDI controller, which will allow bidirectional communication between switcher and foot controller as well as phantom powering.

Important note! Do not connect MIDI devices to both the front panel MIDI input and the rear panel MIDI input at the same time! At best, it won’t work, and in the worst case you can damage your equipment.

Function Switching a.k.a. Controlling Your Amp

The Effect Gizmo has the ability to control footswitchable features on many amps. This could be channel switching, reverb, tremolo, etc. – anything that is controlled by a ¼” footswitch jack. Loops 9 through 12 can be used for function switching purposes. To use one or more of these loops for this purpose, connect a standard ¼” guitar cable from the Out jack of the loop. Make sure nothing is connected to the In, Send or Return jacks of the loop. Connect the other end of your cable to the footswitch jack of the amp. Pressing the loop button on the Effect Gizmo should now control the same channel or function that your footswitch did. You can save the state of this channel or function for every patch, just like you can for the other audio loops.

If your amp has a two button footswitch with a stereo ¼" plug, you can use an insert cable to control it. An insert cable has two mono plugs on one end – these should plug into the outputs of two loops on the Effect Gizmo (any of loops 9-12). The other end of the insert cable has one stereo ¼" plug, and this goes to your footswitch jack. The two loops you selected will control the same channels or functions the amp's footswitch does.

If you have a complex amp with many channels and/or functions, or an amp with an unusual footswitch connector, the Effect Gizmo may not be able to control it. In this case, we recommend our other products such as the Amp Gizmo, Mini Amp Gizmo or RG-16 – all of these are well suited to controlling these amps and are designed to work in conjunction with the Effect Gizmo. These products, and a list of the amps they can control, can be found on our web site.

Stereo Loops

Loops 9 through 12 on the Effect Gizmo are stereo capable. If you plug a stereo or TRS (tip-ring-sleeve) cable into these loops, you can switch stereo unbalanced signals or mono balanced signals. Although they are stereo capable, these loops can always be used for standard mono signals – just be sure to use mono cables.

If you need to connect to equipment that has separate left and right inputs and outputs, you will need to use insert cables to connect it to the Effect Gizmo. These cables have a stereo connector on one end and split the stereo signal to separate left and right connectors.


The Effect Gizmo can also be special ordered with all loops upgraded to stereo capable. Please contact your RJM Music dealer for details.

The following diagrams show some of the many ways you can use your Effect Gizmo in a guitar rig. Please check our web site for more examples.



RJM Music Technology, Inc.
www.rjmmusic.com

Effect Gizmo Wiring Diagram



Effect Gizmo Wiring Diagram
8 pedals, 1 amp, tuner


The guitar signal passes from the front panel jack, through the buffer, then through the first 8 audio loops, and then through the Click Stopper circuit before going to the amp.

The Effect Gizmo controls channel switching on the amp using Audio Loop 12.



RJM Music Technology, Inc.
www.rjmmusic.com

Effect Gizmo Wiring Diagram




Effect Gizmo Wiring Diagram
8 pedals, 2 amps

The guitar signal passes from the front panel jack, through the buffer, through 8 audio loops and the Click Stopper. Loops 9 and 10 are used to split the signal to two amps. Using Loops 9 and 10, you can turn on either amp, both amps, or neither (mute).



RJM Music Technology, Inc.
www.rjmmusic.com

Effect Gizmo Wiring Diagram




Effect Gizmo Wiring Diagram
12 pedals, 1 amp, tuner

The guitar signal passes from the front panel jack, through the buffer, then through the all 12 audio loops, and then through the Click Stopper circuit before going to the amp.



RJM Music Technology, Inc.
www.rjmmusic.com

Effect Gizmo Wiring Diagram



Effect Gizmo Wiring Diagram 10 pedals, 2 amp, tuner


The guitar signal passes from the front panel jack, through the buffer, through 10 audio loops containing pedals, through the Click Stopper circuit and then to loops 11 and 12 which select which amp or amps are active. Turn on loop 11 to activate Amp 1, turn on loop 12 to activate Amp 2.

An isolation transformer (marked "iso" in the diagram) may be needed if you encounter hum when connecting the second amp.



RJM Music Technology, Inc.
www.rjmmusic.com

Effect Gizmo Wiring Diagram



Effect Gizmo Wiring Diagram

8 pedals, 2 stereo effects processors running in effects loops of both amps

The guitar signal passes from the front panel jack, through the buffer, through 8 audio loops and the Click Stopper, then goes to loops 9 and 10. Turning on loop 9 enables the first amp, turning on loop 10 enables the second amp. Loops 11 and 12 turn on the effects processors on both amps. Iso transformers are used to eliminate ground loops. It's best to try everything without the transformers and if you have hum, add them one at a time until the hum goes away.

Note: Dashed lines indicate stereo (TRS) connections.

MIDI Usage

The Effect Gizmo can receive MIDI messages from any MIDI footswitch or other MIDI controller. By storing different settings, or “patches” for different MIDI program numbers, you can automatically recall a stored patch by sending the correct MIDI program number from your footswitch. You can assign which audio loops are on for each and every patch.

To save a setting to a MIDI program number:

- Select a MIDI program number with your MIDI footswitch or controller.
- Manually select the desired state of each Audio Loop using the Effect Gizmo’s front panel buttons.
- Hold down the Write Button (4) until the LEDs flash.

You can save up to 256 patches, using MIDI program numbers 1 through 128 in MIDI banks 0 and 1.

MIDI Continuous Controllers

In addition to supporting MIDI Program Change messages, the Effect Gizmo also supports MIDI Continuous Controller (CC) messages. Using a MIDI controller capable of sending CC messages, you can assign a button on the controller to control an individual loop. For example, you can have a button on your controller assigned to turn an overdrive pedal on or off without affecting any of the other loops.

By default, the following continuous controller numbers are used:

Audio Loop	CC number
Loop 1	80
Loop 2	81
Loop 3	82
Loop 4	83
Loop 5	84
Loop 6	85
Loop 7	86
Loop 8	87
Loop 9	88
Loop 10	89
Loop 11	90
Loop 12	91

The Continuous Controller ranges can be adjusted in Setup Mode.

Each Continuous Controller message has a value assigned to it. Values in the range of 0...63 will turn a loop or switch off, and values of 64...127 will turn it on.

Please note that Continuous Controller messages operate exactly the same as pressing buttons on the front panel. All Setup Mode options such as invert, group and momentary modes will be in effect when processing CC messages.

Bank Selection

The Effect Gizmo can store programs in MIDI banks 0 and 1, for a total of 256 programs. Continuous Controller #0 (Bank MSB) is used to select the current MIDI bank. Bank numbers above bank 1 are ignored.

By default, bank selection is disabled. You can enable bank selection using Setup Mode (see Setup Mode section).

Backing Up Your Settings: SysEx Dump

A SysEx (System Exclusive) data dump will send the current Effect Gizmo system configuration out through the MIDI Thru/Out port. You can then save this data to your computer, or copy the settings directly to another Effect Gizmo.

Hold down the Audio Loop 5 button while powering up the Effect Gizmo, and the Effect Gizmo will immediately send the SysEx Dump. It only takes a couple of seconds to complete.

If you wish to copy settings from one Effect Gizmo to another, connect the MIDI Thru/Out jack of the transmitting unit to the MIDI In jack of the receiving unit, then power up the transmitting unit while holding down the Audio Loop 5 button. (Note that the receiving Effect Gizmo must be powered on and **not** in Setup Mode in order to receive a SysEx dump.) The receiving unit will display a progress bar on its front panel LEDs. The transfer goes very quickly, taking only a couple of seconds. In the case of an error, the receiving unit will flash all LEDs 5 times.

Once the transfer completes, the receiving unit will reset, then return to normal operating mode. The receiving unit now has an exact copy of the transmitting unit's settings.

Setup Mode

To configure the Effect Gizmo, you must first enter Setup Mode. Holding down selected buttons while powering the unit on will bring up selected setup modes, as detailed in this section.

Selecting MIDI Channel and MIDI Options

Hold the Audio Loop 1 button while powering the Effect Gizmo on. Keep holding the button until the LEDs flash. The Audio Loop buttons will then allow you to select the MIDI channel the Effect Gizmo responds to as well as set other MIDI related options.

MIDI Channels

The Effect Gizmo is set by default to send and receive on MIDI Channel 1. To change the send/receive channel, use the Audio Loop buttons to select the channel as shown below:

MIDI Channel	Audio Loop 1 LED	Audio Loop 2 LED	Audio Loop 3 LED	Audio Loop 4 LED
1	OFF	OFF	OFF	OFF
2	ON	OFF	OFF	OFF
3	OFF	ON	OFF	OFF
4	ON	ON	OFF	OFF
5	OFF	OFF	ON	OFF
6	ON	OFF	ON	OFF
7	OFF	ON	ON	OFF
8	ON	ON	ON	OFF
9	OFF	OFF	OFF	ON
10	ON	OFF	OFF	ON
11	OFF	ON	OFF	ON
12	ON	ON	OFF	ON
13	OFF	OFF	ON	ON
14	ON	OFF	ON	ON
15	OFF	ON	ON	ON
16	ON	ON	ON	ON

You can also set a few other MIDI-related options using the other Audio Loop buttons:

Continuous Controller Ranges

The Audio Loop 5 and 6 buttons control the Continuous Controller range for Audio Loops 1 through 8:

Audio Loop 1-8 CC Range	GCX Number	Audio Loop 5 LED	Audio Loop 6 LED
80...87 (default)	1	OFF	OFF
88...95	2	ON	OFF
64...71	3	OFF	ON
56...63	4	ON	ON

The Audio Loop 7 and 8 buttons control the Continuous Controller range for Audio Loops 9 through 12:

Audio Loop 9-12 CC Range	GCX Number	Audio Loop 7 LED	Audio Loop 8 LED
80...83	1	OFF	OFF
88...91 (default)	2	ON	OFF
64...67	3	OFF	ON
56...59	4	ON	ON

[GCX Compatibility Mode](#)

The Audio Loop 9 button turns on GCX compatibility mode for Audio Loops 1-8. This makes the Audio Loops respond to MIDI commands like the GCX switcher, manufactured by Voodoo Lab. In GCX compatibility mode, the Audio Loops respond only to Continuous Controller messages on MIDI channel 16, regardless of the MIDI channel setting. The GCX number is set by Audio Loop buttons 5 and 6 (see above).

The Audio Loop 10 button turns on GCX compatibility mode for Audio Loops 9-12. The GCX number is set by Audio Loop buttons 7 and 8 (see above).

[CC Disable](#)

The Audio Loop 11 button turns on CC Disable mode. This mode prevents the Effect Gizmo from responding to Continuous Controller messages, and is primarily used when debugging a rig. In most circumstances, it's best to keep this option off.

[Bank Select Enable](#)

The Audio Loop 12 button controls whether or not the Effect Gizmo will allow MIDI bank selection. When the Audio Loop 12 button is off, the Effect Gizmo will ignore MIDI bank select messages. When the Audio Loop 12 button is on, the Effect Gizmo will respond to bank select messages as described on page 10.

[Saving MIDI Channel and Options](#)

Once you've set the MIDI channel and options, press the Write button. The Effect Gizmo is now in normal operational mode.

Invert Mode

Invert mode can be used when controlling an amplifier's channel switching with Audio Loops 9 through 12. Some amplifiers may have inverted polarity on their channel or function switching. This can cause the Effect Gizmo to display a function as off when the function is actually on, and as on when the function is actually off. To correct this, you must first switch the Effect Gizmo to Invert Mode.

Hold down the Audio Loop 2 button while powering up the Effect Gizmo. Keep holding the button until the LEDs flash. You are now in Invert Mode.

While in invert mode, use the front panel buttons to light the LED of any function that is inverted. Make certain no other LED is lit.

Once you've selected the inverted function's associated button(s), press the Write button. The Effect Gizmo is now in normal operational mode, and the inverted functions should operate correctly.

Momentary Mode

Momentary mode can also be used when controlling channels or functions on an amplifier. Some devices require momentary-type switching, rather than the more common latching-type switches. (A momentary switch changes

OFF/ON state by closing its contacts for a short time and then re-opening them. In momentary mode, the Effect Gizmo switches will close for 100 milliseconds before opening again.)

To enter momentary mode, hold down the Audio Loop 3 button while powering up the Effect Gizmo. Keep holding the button until the LEDs flash. Use the front panel buttons to light the LED of any function that needs to be momentary. Make certain that no other LED is lit.

Once you've selected the buttons for the momentary functions, press the Write button. The Effect Gizmo is now in normal operational mode and the momentary functions should operate correctly.

Group Mode

The Group feature allows you define a group of buttons where pressing one button of the group turns that button on and turns all other buttons in the group off. This is typically used for function switches that control which channel is selected on an amplifier. This prevents the Effect Gizmo from trying to activate more than one amp channel at a time.

To enter group mode, hold down the Audio Loop 4 button while powering up the Effect Gizmo. Keep holding the button until the LEDs flash.

Use the front panel buttons to light the LED of any function that should be in the group. Make sure that no other LEDs are lit.

Note: The groups for Audio Loops 1-6 and Audio Loops 7-12 are separate. Pressing a button in the Audio Loop 1-6 range only affects loops 1-6. Pressing a button in the Audio Loop 7-12 range only affects loops 7-12.

Once you've selected the loops that need to be grouped, press the Write button. The Effect Gizmo is now in normal operational mode and the grouped buttons will now only allow one button to be selected at a time.

Factory Reset

To restore the Effect Gizmo to the factory settings, hold the Audio Loop 1 and Audio Loop 4 buttons while powering up the Effect Gizmo. All of the LEDs will turn on for a few seconds, then turn off. Once they turn off, factory reset is complete and you can release the Audio Loop 1 and 4 buttons. The Effect Gizmo is now in normal operational mode.

Troubleshooting

Problem: The LEDs don't flash when you hold down the Write Button.

Solution: The Effect Gizmo did not receive a MIDI Program Change message. First, verify that you have a valid MIDI connection. The MIDI output of your MIDI controller should be connected to the MIDI input of the Effect Gizmo by a MIDI cable that's known to be working correctly. The next most likely cause is that the Effect Gizmo is set to a different MIDI channel than your MIDI controller. Check both devices to insure that they're set to the same channel. On the Effect Gizmo, the MIDI channel is set to 1 by default and can be changed in Setup Mode.

Problem: There is excessive hum in the audio signal.

Solution: There are a number of reasons that this might happen, but it's often a ground loop or other grounding problem. Please refer to the Grounding Issues section of this manual.

Problem: The Audio Loop 1 and/or Audio Loop 7 lights are flashing. Also, the Effect Gizmo may not be switching properly.

Solution: Those lights flash to indicate that the voltage being supplied to the Effect Gizmo isn't sufficient to power it reliably. This probably means you're using a 9VDC power supply instead of the required 9VAC or 12VDC supply. Switch to the correct power supply and the symptoms should go away.

Problem: The signal coming out of the buffer is too loud, or is clipped.

Solution: There is a buffer level adjustment inside the Effect Gizmo. This is set to unity gain at the factory, but can be adjusted to provide a boost. Remove the Effect Gizmo lid (you need to remove two screws on the top, two on each side, and one on the top center of the front panel). The level adjustment is a small blue trimpot near the front panel input jack. Using a Philips screwdriver, gently turn it all the way counterclockwise for unity gain, or clockwise for a volume boost.

More troubleshooting tips can be found in the RJM Music Forum: www.rjmmusic.com/forum.

Grounding Issues

Guitar rigs are complex electrical systems, and rigs with switching systems are among the most complex. The more complex the rig, the more likely you are to encounter grounding issues. Every audio path in the system must be shielded, with a good connection to ground, or you may get audio hum or buzz due to electromagnetic interference. However, if there are too many connections to ground, you can get a ground loop, which also causes hum.

So, if you're experiencing hum, what do you do?

Step 1: Press the Gnd Lift button on the back of the Effect Gizmo. This will either connect or disconnect the ground connection to the Effect Gizmo's metal enclosure. (In means disconnected (lifted), out means connected). If you're lucky, that will solve the problem.

Step 2: Are you using either the buffer or Click Stopper? If either is connected in your audio path, then you can skip to Step 3. If neither is connected, try using the buffer. This may provide a needed path to ground. Also, for this test, make sure that the Gnd Lift switch is in the out (connected) position.

Step 3: Check what you're using to power your effect pedals. A multiple output power supply that doesn't have isolated outputs is a common source of ground loops. Power supplies that have "daisy chain" power cords, where there are multiple power connectors on a single cord are definitely not isolated, and there are many other non-isolated culprits on the market. You can test for isolation by unplugging the power cable from every pedal. If the hum goes away, you need to upgrade to a better (isolated) power supply!

Step 3: If you have more than one amp connected, disconnect the audio connection(s) to one of the two amps. If the hum goes away, you need an isolation transformer to isolate either the audio or power connection on the second amp.

Step 4: If you're running a split effects setup where some pedals are connected to the amp's input and others are connected in the amp's loop, you should try to use an isolation transformer on the lead running from the amp's loop return to the Effect Gizmo. Alternately, you can use a ground lift cable¹ - it can work as well as an isolation transformer.

Step 5: If none of the above steps have helped, you'll need to do some detective work. Begin disconnecting your effects, starting with any rack-mounted effects. At some point, the hum will stop (at least, we hope so!) You will need to use an isolation transformer or ground lift cable on the lead coming out of the effect's output (and possibly the input as well). Do this for the last effect you disconnected, and start reconnecting everything. If the hum comes back, isolate the last effects device you just connected. Repeat this until you are hum free.


This is only a brief guide giving you the basic steps – there are, unfortunately, many other ways for ground loops to find their way into your rig. If you can't figure it out, you may need to enlist the services of a competent tech – someone who's used to chasing down these kinds of problems.

¹ A ground lift cable is an audio cable that has the shield or ground disconnected on one side. They're very useful to have around when building a guitar rig!

Specifications

Dimensions	Standard 1U EIA rack enclosure 19 (W) x 1.75 (H) x 7.25 (D) inches 48.3 (W) x 4.5 (H) x 18.5 (D) cm
Weight	4 lbs, 12 oz 2.15 kg
Power	9VAC @ 550mA, 12VDC also acceptable (9VAC @ 700mA for full-stereo model) 5.5mm OD, 2.1mm ID x 9.5mm barrel connector
Phantom Power	Provided over pins 6 and 7 of the MIDI In jack Voltage provided is the same as power applied at the Effect Gizmo power jack 9VAC, maximum 450mA current when using provided AC adaptor (max. 300mA for full stereo version with provided AC adaptor)
Memory	256 programs, arranged in 2 banks of 128 Memory is non-volatile and requires no backup battery

Front Panel MIDI Connector



The front panel MIDI connector is a female 6-pin XLR connector. This connector carries MIDI data in both directions as well as phantom power. This connector is wired in parallel with the rear panel MIDI input, so it is very important to only use one of the two connectors at a time.

The pinout is as follows:

- 1:** Phantom power (power jack tip)
- 2:** Phantom power (power jack sleeve)
- 3:** MIDI output (pin 4 on a standard MIDI output)
- 4:** MIDI output (pin 5 on a standard MIDI output)
- 5:** MIDI input (pin 4 on a standard MIDI input)
- 6:** MIDI input (pin 5 on a standard MIDI input)

The recommended mating connectors are Neutrik part numbers NC6MX or NC6MXX.

Effect Gizmo MIDI Implementation Chart

MIDI Implementation Chart v 2.0 (Page 1 of 3)				
Manufacturer: RJM Music Technology, Inc. Model: Effect Gizmo Version: 1 Date: November 5, 2012				
		Transmit/Export	Recognize/Import	Remarks
1. Basic Information				
MIDI Channels		1-16	1-16	Channel 1 is set by default
Note Numbers		No	No	
Program change		1-128	1-128	
Bank Select Response? (Yes/No)		No	No	Responds to CC#0 only, Uses banks 0 and 1
If yes, list banks utilized in remarks column				
Modes supported :	Mode 1: Omni-On, Poly (Yes/No)	No	No	
	Mode 2: Omni-On, Mono (Yes/No)	No	No	
	Mode 3: Omni-Off, Poly (Yes/No)	Yes	Yes	
	Mode 4: Omni-Off, Mono (Yes/No)	Yes	Yes	
	Multi Mode (Yes/No)	No	No	
Note-On Velocity (Yes/No)		No	No	
Note-Off Velocity (Yes/No)		No	No	
Channel Aftertouch (Yes/No)		No	No	
Poly (Key) Aftertouch (Yes/No)		No	No	
Pitch Bend (Yes/No)		No	No	
Active Sensing (Yes/No)		No	No	
System Reset (Yes/No)		No	No	
Tune Request (Yes/No)		No	No	
Universal System Exclusive:	Sample Dump Standard (Yes/No)	No	No	
	Device Inquiry (Yes/No)	No	No	
	File Dump (Yes/No)	No	No	
	MIDI Tuning (Yes/No)	No	No	
	Master Volume (Yes/No)	No	No	
	Master Balance (Yes/No)	No	No	
	Notation Information (Yes/No)	No	No	
	Turn GM1 System On (Yes/No)	No	No	
	Turn GM2 System On (Yes/No)	No	No	
	Turn GM System Off (Yes/No)	No	No	
	DLS-1 (Yes/No)	No	No	
	File Reference (Yes/No)	No	No	
	Controller Destination (Yes/No)	No	No	
	Key-based Instrument Ctrl (Yes/No)	No	No	
Master Fine/Coarse Tune (Yes/No)	No	No		
Other Universal System Exclusive	No	No		
Manufacturer or Non-Commercial System Exclusive		Yes	Yes	RJM Music Technology, Inc Manuf. ID: 00 01 5B
NRPNs (Yes/No)		No	No	
RPN 00 (Pitch Bend Sensitivity) (Yes/No)		No	No	
RPN 01 (Channel Fine Tune) (Yes/No)		No	No	
RPN 02 (Channel Coarse Tune) (Yes/No)		No	No	
RPN 03 (Tuning Program Select) (Yes/No)		No	No	
RPN 04 (Tuning Bank Select) (Yes/No)		No	No	
RPN 05 (Modulation Depth Range) (Yes/No)		No	No	
2. MIDI Timing and Synchronization				
MIDI Clock (Yes/No)		No	No	
Song Position Pointer (Yes/No)		No	No	
Song Select (Yes/No)			No	
Start (Yes/No)		No	No	
Continue (Yes/No)		No	No	
Stop (Yes/No)		No	No	
MIDI Time Code (Yes/No)		No	No	
MIDI Machine Control (Yes/No)		No	No	
MIDI Show Control (Yes/No)				
If yes, MSC Level supported		No	No	
3. Extensions Compatibility				
General MIDI compatible? (Level(s)/No)		No	No	
Is GM default power-up mode? (Level/No)		No	No	
DLS compatible? (Levels(s)/No)		No	No	
(DLS File Type(s)/No)		No	No	
Standard MIDI Files (Type(s)/No)		No	No	
XMF Files (Type(s)/No)		No	No	
SP-MIDI compatible? (Yes/No)		No	No	

MIDI Implementation Chart v 2.0 (Page 2 of 3)				
Manufacturer: RJM Music Technology, Inc. Model: Effect Gizmo Version: 1 Date: November 5, 2012				
Control #	Function	Transmitted (Y/N)	Recognized (Y/N)	Remarks
0	Bank Select (MSB)	N	Y	Banks 0 and 1 only
1	Modulation Wheel (MSB)	N	N	
2	Breath Controller (MSB)	N	N	
3		N	N	
4	Foot Controller (MSB)	N	N	
5	Portamento Time (MSB)	N	N	
6	Data Entry (MSB)	N	N	
7	Channel Volume (MSB)	N	N	
8	Balance (MSB)	N	N	
9		N	N	
10	Pan (MSB)	N	N	
11	Expression (MSB)	N	N	
12	Effect Control 1 (MSB)	N	N	
13	Effect Control 2 (MSB)	N	N	
14		N	N	
15		N	N	
16	General Purpose Controller 1 (MSB)	N	N	
17	General Purpose Controller 2 (MSB)	N	N	
18	General Purpose Controller 3 (MSB)	N	N	
19	General Purpose Controller 4 (MSB)	N	N	
20		N	N	
21		N	N	
22		N	N	
23		N	N	
24		N	N	
25		N	N	
26		N	N	
27		N	N	
28		N	N	
29		N	N	
30		N	N	
31		N	N	
32	Bank Select (LSB)	N	N	Use CC#0 instead
33	Modulation Wheel (LSB)	N	N	
34	Breath Controller (LSB)	N	N	
35		N	N	
36	Foot Controller (LSB)	N	N	
37	Portamento Time (LSB)	N	N	
38	Data Entry (LSB)	N	N	
39	Channel Volume (LSB)	N	N	
40	Balance (LSB)	N	N	
41		N	N	
42	Pan (LSB)	N	N	
43	Expression (LSB)	N	N	
44	Effect Control 1 (LSB)	N	N	
45	Effect Control 2 (LSB)	N	N	
46		N	N	
47		N	N	
48	General Purpose Controller 1 (LSB)	N	N	
49	General Purpose Controller 2 (LSB)	N	N	
50	General Purpose Controller 3 (LSB)	N	N	
51	General Purpose Controller 4 (LSB)	N	N	
52		N	Y	
53		N	Y	
54		N	Y	
55		N	Y	
56		N	Y	Alt. CC Range 2
57		N	Y	Alt. CC Range 2
58		N	Y	Alt. CC Range 2
59		N	Y	Alt. CC Range 2
60		N	Y	Alt. CC Range 2
61		N	Y	Alt. CC Range 2
62		N	Y	Alt. CC Range 2
63		N	Y	Alt. CC Range 2

MIDI Implementation Chart v 2.0 (Page 3 of 3)				
Manufacturer: RJM Music Technology, Inc. Model: Effect Gizmo Version: 1 Date: November 5, 2012				
Control #	Function	Transmitted (Y/N)	Recognized (Y/N)	Remarks
64	Sustain Pedal	N	Y	Alt. CC Range 1
65	Portamento On/Off	N	Y	Alt. CC Range 1
66	Sostenuto	N	Y	Alt. CC Range 1
67	Soft Pedal	N	Y	Alt. CC Range 1
68	Legato Footswitch	N	Y	Alt. CC Range 1
69	Hold 2	N	Y	Alt. CC Range 1
70	Sound Controller 1 (default: Sound Variation)	N	Y	Alt. CC Range 1
71	Sound Controller 2 (default: Timbre / Harmonic Quality)	N	Y	Alt. CC Range 1
72	Sound Controller 3 (default: Release Time)	N	N	
73	Sound Controller 4 (default: Attack Time)	N	N	
74	Sound Controller 5 (default: Brightness)	N	N	
75	Sound Controller 6 (GM2 default: Decay Time)	N	N	
76	Sound Controller 7 (GM2 default: Vibrato Rate)	N	N	
77	Sound Controller 8 (GM2 default: Vibrato Depth)	N	N	
78	Sound Controller 9 (GM2 default: Vibrato Delay)	N	N	
79	Sound Controller 10 (GM2 default: Undefined)	N	N	
80	General Purpose Controller 5	N	Y	Audio Loop 1
81	General Purpose Controller 6	N	Y	Audio Loop 2
82	General Purpose Controller 7	N	Y	Audio Loop 3
83	General Purpose Controller 8	N	Y	Audio Loop 4
84	Portamento Control	N	Y	Audio Loop 5
85		N	Y	Audio Loop 6
86		N	Y	Audio Loop 7
87		N	Y	Audio Loop 8
88		N	Y	Audio Loop 9
89		N	Y	Audio Loop 10
90		N	Y	Audio Loop 11
91	Effects 1 Depth (default: Reverb Send)	N	Y	Audio Loop 12
92	Effects 2 Depth (default: Tremolo Depth)	N	Y	
93	Effects 3 Depth (default: Chorus Send)	N	Y	
94	Effects 4 Depth (default: Celeste [Detune] Depth)	N	Y	
95	Effects 5 Depth (default: Phaser Depth)	N	Y	
96	Data Increment	N	N	
97	Data Decrement	N	N	
98	Non-Registered Parameter Number (LSB)	N	N	
99	Non-Registered Parameter Number (MSB)	N	N	
100	Registered Parameter Number (LSB)	N	N	
101	Registered Parameter Number (MSB)	N	N	
102		N	N	
103		N	N	
104		N	N	
105		N	N	
106		N	N	
107		N	N	
108		N	N	
109		N	N	
110		N	N	
111		N	N	
112		N	N	
113		N	N	
114		N	N	
115		N	N	
116		N	N	
117		N	N	
118		N	N	
119		N	N	
120	All Sound Off	N	N	
121	Reset All Controllers	N	N	
122	Local Control On/Off	N	N	
123	All Notes Off	N	N	
124	Omni Mode Off	N	N	
125	Omni Mode On	N	N	
126	Poly Mode Off	N	N	
127	Poly Mode On	N	N	

Warranty

RJM Music Technology, Inc. warrants this product against any defects in material or workmanship for a period of five years from the original date of purchase.

Should you experience any difficulty with this RJM Music product, please contact us as described below. If it is determined that the product has become defective within the warranty period and must be returned to the factory, RJM Music Technology will issue a Returned Merchandise Authorization (RMA) number and shipping and packaging instructions.

RJM Music Technology will repair or replace the product free of charge, provided it is returned freight prepaid to RJM Music Technology with a copy of a valid receipt and RMA number. Return shipping will be paid by RJM Music Technology within the U.S. only.

This warranty is transferable provided the current owner has the original dated purchase receipt and can provide a copy of it when submitting the warranty claim.

This warranty shall not apply to any goods that have been repaired or altered by anyone other than RJM Music Technology, Inc. or an RJM Music Technology authorized service center. This warranty does not cover damage to the product resulting from accidents or misuse. This is your sole warranty. There are no warranties which extend beyond the terms described herein.

RJM Music Technology, Inc.
2525 Pioneer Ave.
Suite 1
Vista, CA 92081
+1-760-597-9450
E-Mail: support@rjmmusic.com

