



MULTIBOX CONFIGURATION DIAGRAM

MIDI Thru Box

This configuration turns the MultiBox into a MIDI thru box. Connect your MIDI controller or other MIDI data source to the input, then the box will split the MIDI signal into 3 standard 5-pin DIN MIDI connections and 4 TRS MIDI connections.



Internal Jumper Configuration



TRS MIDI Jumpers

Each TRS MIDI jack has two jumpers next to it, one with 2 pins and one with 3. There are three different jumper settings that can be selected which determine what devices it's compatible with. If your device is not listed here, consult your device's user manual to determine which option to select.

- Tip Active (Strymon, Eventide, Empress, etc.) (default)
- Ring Active (Chase Bliss)
- Standard MIDI (Boss, etc.)

Other configuration diagrams are available at rjmmusic.com